

MAY 2016

	New Products
	New Price Increase
	New Price Decrease
	Promotion
	Extended Promotion
	Discontinued
	Authorized Reseller Only
	4k modification process
	Replacement Parts
	Being Discontinued Soon
	New PTF



Sachtler

List Of All Products

Product ID	Product Name	Description
Sachtler-3987	Accessory Mount Kit	Accessory mount with 1/4 in., 3/8 in., M8 tap holes
Sachtler-1021	Ace Accessories Kit	Ace Base Plate (S2154-0001) + Ace Matte Box (S2152-0001) + Ace Follow Focus (S2153-0001) + one pair of rods (S2154-1905)
Sachtler-1022	Ace Accessories Kit incl Shoulder Rig	Includes: S2152-0001 Ace Matte Box + S2153-0001 Ace Follow Focus + S2154-0001 Ace Base Plate + 2158-0001 Ace Shoulder Rig + S2153-1202 Ace Height Extender
Sachtler-S2154-0001	Ace Base Plate	Ace Base Plate + camera plate + anti-twist block + spare camera screws height adjustable from 4.8 - 7.2 cm (1.9 - 2.8 in); max payload 7 kg (15.4 lbs)
Sachtler-S2152-1200	Ace donuts, set of 20	size 50 mm (1.97 in) x 143 mm (5.63 in) + size 77 mm (3.03 in) x 143 mm (5.63 in)
Sachtler-S2153-1004	Ace Drive gear, 50t, 0.8module	Ace Drive gear, 50t, 0.8module
Sachtler-S2152-1201	Ace Filter Frames 4" x 4", set of two	Ace Filter Frames 4" x 4", set of two
Sachtler-S2152-1202	Ace Filter Frames 4" x 5.65", set of two	Ace Filter Frames 4" x 5.65", set of two
Sachtler-S2153-0001	Ace Follow Focus	Ace Follow Focus with hard stops + one friction wheel + one drive gear + two marking disks
Sachtler-S2153-1003	Ace Friction wheel	Ace Friction wheel
Sachtler-S2153-1202	Ace Height Extender	height extension for Follow Focus by 26.75 mm
Sachtler-1020	Ace L fluid head	Ace L fluid head, 75 mm bowl or flat base, 0.76 kg (0.7 13.2 lbs) payload, 3+3 drag, 7 + 0 counterbalance, 1 pan bar
Sachtler-1023	Ace L incl Ace Accessories package	Package includes: S2152-0001 Ace Matte Box S2153-0001 Ace Follow Focus S2154-0001 Ace Base Plate S2158-0001 Ace Shoulder Rig S2154-1905 Ace Rods Ø 15 mm
Sachtler-S2153-1200	Ace Marking disks, set of 5	Ace Marking disks, set of 5
Sachtler-S2152-0001	Ace Matte Box	Ace Matte Box with two filter stages (one rotating) + top flag + two side flags + two filter frames 4" x 4" + two filter frames 4" x 5.65" + two donuts.
Sachtler-S2154-1905	Ace Rods Ø 15 mm rods, set with two units	length 30 cm (11.8 in)
Sachtler-S2158-0001	Ace Shoulder Rig	Ace shoulder mount + Ace hand grips + pair of rods 30 cm long + pair of rods 15 cm long + rod connectors (2) + offset mount + counterweight + spacers for
Sachtler-S2152-2011	Ace Side Flag, left	Ace Side Flag, left
Sachtler-S2152-2009	Ace Side Flag, right	Ace Side Flag, right
Sachtler-S2152-1015	Ace Top Flag	Ace Top Flag
Sachtler-3901	Adapter 100/150	for fluid heads with 100 mm ball on tripods with 150 mm mount
Sachtler-3906	Adapter 75/100	for fluid heads with 75 mm ball on tripods with 100 mm mount
Sachtler-3985	Adapter accessory, 1/4", 3/8", M8	for fluid heads with adapter viewfinder extension
Sachtler-6052	Adapter ball with screw	for fluid heads Video 25 Plus FB, Video 60 Plus Studio and Video 75 Plus Studio - converts FB to ball
Sachtler-3903	Adapter FB/100	for fluid heads with 100 mm ball on FB tripods and pedestals
Sachtler-3908	Adapter FB/150	for fluid heads with 150 mm ball on FB tripods and pedestals
Sachtler-1030	Adapter Ped C I/DV	for fluid heads DV 10, DV 12 and Video 15 on Pedestal C I
Sachtler-6053	Adapter piece Mitchell with locking knob	for fluid heads Cine 30 HD, Studio 9+9 and Cine 75 HD on Mitchell tripod - attaches to head via 4 screws
Sachtler-3980	Adapter viewfinder extension 12/15	for fluid heads DV 12 SB and Video 15 SB
Sachtler-3981	Adapter viewfinder extension 18/20	for fluid heads Video 18/20 S1/SB, Video 18 Plus since 05/2005 and Video 20 Plus since 2002
Sachtler-1063	C.O.G. Plate	for fluid heads DV 12, Video 15, Video 18, Video 20 and Video 25 Plus to compensate for front / backheavy cameras
Sachtler-1465	C.O.G. Plate DV	for fluid heads FSB 6 T and FSB 8 T if front- or backheavy
Sachtler-6054	Cable clamp V 60	for fluid heads Video 25 Plus, Cine 30 HD, Video 60 Plus, Video 90
Sachtler-6055	Cable clamp V/C 75	for fluid heads Video 75 Plus and Cine 75 HD
Sachtler-8676	Carrying strap 75	for tripod Speed Lock 75 CF
Sachtler-8677	Carrying strap Ace	for systems Ace M and Ace L (except system Ace L TT 75/2 CF)
Sachtler-8690	Carrying strap ENG 2	for tripods Speed Lock CF, ENG 2, Hot Pod, DA 100 HD, EFP 2, CF 150 and DA 150 (except DA 150 K)
Sachtler-9503	Case 30	for fluid head Cine 30 HD
Sachtler-9513	Case 60 FB	for fluid head Video 60 Plus Studio
Sachtler-9511	Case 9+9	for fluid heads Studio 9+9, Video 60 Plus EFP
Sachtler-9512	Case 90	for fluid head Video 90
Sachtler-9517	Case V/C 75	for fluid heads Video 75 Plus Studio, Video 75 Plus EFP, Cine 75 HD
Sachtler-3006	Cine 30 HD	150 mm, 7+7 drag, sideload plate 30 HD, 1 telescopic pan bar
Sachtler-1910	Cine 7+7 HD	100 mm, 7+7 drag, sideload plate M, 1 telescopic pan bar
Sachtler-7502	Cine 75 HD	150 mm, 9+9 drag, Touch & Go plate 35, 1 telescopic pan bar
Sachtler-5199	Combi Ped 1-40	flat base mount; features one lift air column; height range 30.7 - 52 in (78-132 cm); compatible fluid heads: Video 25 Plus FB; DV 10, DV 12, Video 15 with
Sachtler-5207	Compressor	adapter 3914; Video 18/20 S1/SB/Plus with adapter 3913;
Sachtler-9201	Cover 100 K	also for Pedestal C III and Combi Ped 1-40; Z30 V only
Sachtler-9309	Cover 100 II	for tripod DA 100 K, with spreader, without fluid head
Sachtler-9214	Cover 100 M	for fluid heads DV 10, DV 12, Video 15/18/20 on tripods 100 long/100 HD with spreader and on Hot Pod
Sachtler-9312	Cover 150 L	for tripod 100 medium, with spreader, without fluid head
Sachtler-9310	Cover 150 II	for fluid heads Video 18/20 on tripods ENG 2 heavy duty and Speed Lock CF HD (without ground spreader); for tripods DA/CF 150 L with spreader, without fluid head
Sachtler-9308	Cover 150 M	for fluid heads Video 25 Plus on tripods medium long with spreader, Video 60 Plus EFP (without pan bars) on tripods EFP 2 and Video 25 Plus FB on tripod OB 2000
Sachtler-9316	Cover 150 SE	for tripod DA 150 M with spreader, without fluid head
Sachtler-9504	Cover 25	for Dolly 5 and Dolly DV 100; tripods EFP 2 with spreader (without fluid head)
Sachtler-9320	Cover Cine L	for tripod Cine 2000 short with spreader, without fluid head
Sachtler-9317	Cover Cine M	for tripod Cine long with spreader, without fluid head
Sachtler-9213	Cover DV 2	for tripod Cine medium with spreader, without fluid head
Sachtler-9315	Cover EFP 2	for fluid heads FSB on tripods Speed Lock 75 CF and ENG 75/2 D
Sachtler-9311	Cover ENG 2	for fluid heads Video 18/20 on tripod Speed Lock CF HD with ground spreader and Video 25 Plus on tripods EFP 2 as well as tripod OB 2000 with spreader, without fluid head
Sachtler-7085	Dolly Cine	for fluid heads DV 10, DV 12, Video 15/18/20 on tripods ENG 2, Speed Lock CF; for FSB, DV fluid heads and Video 15, Video 18 on pedestal C I (w/o dolly)
Sachtler-7067	Dolly DV 100	4.9 in (125 mm) wheel diameter with eccentric locking for tripods Cine long and medium
Sachtler-7063	Dolly DV 75	for systems DV 10, DV 12 and Video 15 and SOOM
Sachtler -v-7065	Dolly 5	for tripods 75 mm (except SOOM, system Ace M, MS and system Ace L TT 75/2 CF)
Sachtler-7080	Dolly XL	for tripods 100/150 mm (except Hot Pod, DA 100 K, DA 150 K, Cine 150) and SOOM; 4.9 in (100 mm) wheels; includes cable guards and tracking locks
Sachtler-165	DSLR plate	4.9 in (125 mm) wheel diameter with eccentric locking for tripod OB 2000; includes cable guards and tracking locks
Sachtler-3004	Dutch Head 35	for fluid heads Ace, FSB 4, FSB 6 and FSB 8
Sachtler-1006	DV 10 SB	on fluid heads with Touch & Go plate 35, 7+7 drag, 1 telescopic pan bar
Sachtler-1075	DV 100	100 mm or FB, 5+5 drag, Touch & Go plate S, 1 pan bar
Sachtler-1205	DV 12 SB	Pan Bar for fluid heads DV 10 und DV 12
Sachtler-3470	DV right (telescopic)	100 mm or FB, 5+5 drag, Touch & Go plate 16, 1 pan bar
Sachtler-3083	ENG adapter plate	for all FSB fluid heads and Video 15
Sachtler-3913	FB Converter	for ENG cameras on fluid heads Video 60 Plus Studio, Video 75 Plus Studio and Video 90
Sachtler	Front pan bar	flat base for fluid heads Video 18/20 SB/Plus on Pedestals and OB tripods (except Pedestal C I)
Sachtler-3372	Front pan bar HD	for fluid heads Video 75 Plus and Cine 75 HD
Sachtler	Front pan bar HD S	for fluid head Cine 30 HD
Sachtler-307	FSB 4	for fluid head Cine 7+7 HD
Sachtler-407	FSB 6	75 mm or FB, 3+3 drag, sideload plate S, 1 pan bar
Sachtler-405	FSB 6 T	75 mm or FB, 3+3 drag, sideload plate S, 1 pan bar
Sachtler-707	FSB 8	75 mm or FB, 3+3 drag, Touch & Go plate S, 1 pan bar
Sachtler-705	FSB 8 T	75 mm or FB, 5+5 drag, sideload plate S, 1 pan bar
Sachtler-7023	Ground spreader Cine	75 mm or FB, 5+5 drag, Touch & Go plate S, 1 pan bar
Sachtler-7002	Ground spreader SP 100	heavy duty ground spreader with eccentric locking for tripods Cine 150 long/medium
Sachtler-7003	Ground spreader SP 100/150	lightweight ground spreader for all tripods with 100 mm bowl (except DA 100 K)
Sachtler-7013	Ground spreader SP 150 EX	heavy duty rubber spreader for all tripods 100 and 150 mm bowl (except DA 100 K, DA 150 K and Cine tripod)
Sachtler-7001	Ground Spreader SP 75	ground spreader with eccentric locking for tripod OB 2000
Sachtler-6205	Hand Crank Column OB 2000	for 75 mm tripods (except SOOM, system Ace M, MS and system Ace L TT 75/2 CF)
Sachtler-5385/10	Hot Pod CF 10	Mount: flat base (FB), lift range 14.2 in (36 cm)
Sachtler-5385/14	Hot Pod CF 14	1-stage with pneumatic lift column; for fluid heads DV 10 and DV 12
Sachtler-7066	Hot Pod Dolly	1-stage with pneumatic lift column; for fluid heads Video 15 and Video 18
Sachtler-S2038-1000	Mid level spreader 75 HD	for Hot Pod tripods only; 4.0 in (100 mm) wheel diameter; includes cable guards and tracking locks
Sachtler-7007	Mid-level spreader 100/150	Mid level spreader 75 HD
Sachtler-7027	Mid-level spreader Cine	for all 100/150 mm tripods (except DA 100 K, DA 150 K and Cine tripods)
Sachtler-7002K	Mini ground spreader 100	for tripods Cine long
Sachtler-7003K	Mini ground spreader 150	for tripod DA 100 K
Sachtler-7013K	Mini ground spreader EX	for tripod DA 150 K
Sachtler-5395	Monopod 2 CF	for tripod Cine 2000 short
Sachtler-5396	Monopod 2 CF	Touch & Go plate 16, Sandwich Touch & Go, max. height 65.4 in (166 cm)
Sachtler-3914	Multi Disc	Betacam quick release system, max. height 65.4 in (166 cm)
Vitec-9115	Padded bag Ace	flat base for DV 10, DV 12, Video 15-20 III FB and Euro adapter on Quickfix as well as Video 25 Plus FB, Cine 30 HD, Video 60 Plus Studio, Video 75 Plus Studio and other flat base heads
Sachtler-9109	Padded bag DV 75 L	for systems Ace L
Sachtler-9108	Padded bag DV 75 S	for fluid heads FSB on tripod DA 75 L, TT 75/2 CF and SOOM TriPod System w/o SOOM Tube
Sachtler-9104	Padded bag ENG 2	for fluid heads FSB on tripods Speed Lock 75 CF and ENG 75/2 D
Sachtler-9106	Padded bag ENG/EFP	for fluid heads FB on tripods Speed Lock 75 CF and ENG 75/2 D, and DV 10, DV 12, Video 15/18/20 and Cine 7+7 HD on tripods Speed Lock CF and ENG 2
Sachtler-S2150-1200	Pan Bar Ace	for fluid heads DV10, DV 12, Video 15/18/20 and Cine 7+7 HD on tripods 100 long, 100 heavy duty and Hot Pod as well as on Speed Lock CF HD and ENG 2
Sachtler-B-3074-100	Pan Bar back section left	for fluid heads Ace M and Ace L
Sachtler-B-3073-100	Pan Bar back section right	for fluid heads Video 60 Plus Studio, Video 75 Plus and Video 90
Sachtler-09925P	Pan bar DV 75	for fluid heads Video 60 Plus Studio, Video 75 Plus and Video 90
Sachtler-3471	Pan bar DV left (telescopic)	for fluid heads FSB
Sachtler-3171	Pan Bar front section	for all FSB fluid heads and Video 15
Sachtler-B-3074-020	Pan Bar front section left	for fluid heads Video 60 Plus Studio, Video 75 Plus and Video 90
Sachtler-3371	Pan Bar HD left (telescopic)	for fluid heads Video 60 Plus Studio, Video 75 Plus and Video 90
Sachtler-3370	Pan bar HD right (telescopic)	for fluid heads Cine 7+7 HD and Cine 30 HD
Sachtler-v-3170	Pan bar Movie right (telescopic)	for fluid heads Cine 7+7 HD and Cine 30 HD
Sachtler-3271	Pan bar Plus left (telescopic)	for fluid heads Studio 9+9 and Cine 75 HD
Sachtler-3270	Pan bar Plus right (telescopic)	for fluid heads Studio 9+9 and Cine 75 HD
Sachtler-5195	Pedestal C III	for fluid heads Video 18-25, Dutch Heads, Video 60 Plus EFP
Sachtler-4191	Pedestal C I	for fluid heads Video 18-25, Dutch Heads, Video 60 Plus EFP
Sachtler-3910	Quickfix	flat base mount; features one manually adjusted tripod stage & one 16.5 in (42 cm) lift air column; compatible fluid heads: DV 10, DV 12, Video 15; Video 18/20
Sachtler-7004	Rubber Feet 100/150	flat base mount; features one manually adjusted tripod stage & one 15.4 in (39 cm) lift air column; compatible fluid heads: FSB series; for DV 10, DV 12, Video
Sachtler-7014	Rubber Feet EX	quick mount on pedestals and tripod OB 2000 for Video 90 FB and for Video 25 Plus FB - Video 75 Plus Studio with 3914
Sachtler-S2044-0001	Sachtler SpeedLevel Clamp	set of 3, rubber locking for 100/150 mm tripods (except Cine tripods) and SOOM tripod
Sachtler-1091	Sandwich Touch & Go	set of 3, eccentric locking for tripods Cine long
Sachtler-7011	Set mid-level spreader 75	Sachtler SpeedLevel Clamp
Sachtler-7008	Set mid-level spreader 75 HD	for conversion of other fluid heads, and monopod; with Touch & Go plate 16
Sachtler-3060	Sideload plate 30 HD	set of mid-level spreader 75 plus 3 rubber feet 75 for all 75 mm tripods (except SOOM, systems Ace and tripod ENG 75/2 D HD)
Sachtler-1164	Sideload plate M	set of mid-level spreader 75 HD plus 3 rubber feet 75 for tripod ENG 75/2 D HD
Sachtler-164	Sideload plate S	for fluid head Cine 30 HD
Sachtler-S2003-0003	SOOM TriPod	for fluid head Cine 7+7 HD
Sachtler-S2004-0001	SOOM TriSpread	for fluid heads FSB 4, FSB 6 and FSB 8
Sachtler-S2005-0001	SOOM Tube	1-stage; height 26.8 - 55.9 in (68-142 cm); aluminum
Sachtler-6002	Studio 9+9	mid-level spreader for SOOM TriPod and baby tripod 7.9 - 18.9 in (20-48 cm) as one unit
Sachtler-1062	System 10 SB ENG 2 CF	column 34.6 - 88.6 in (88-225 cm) in TriPod and monopod 34.2 - 61.8 in (87-157 cm) as one unit; requires fluid head
Sachtler-1262	System 12 SB ENG 2 CF	150 mm, 9+9 drag, Touch & Go plate 35, 1 telescopic pan bar
Sachtler-1265	System 12 SB SL MCF	DV 10 SB fluid head (1006) + tripod ENG 2 CF (5386) + spreader SP 100 (7002) + cover ENG 2 (9311)
Sachtler-1562	System 15 SB ENG 2 CF	DV 12 SB fluid head (1205) + tripod ENG 2 CF (5386) + spreader SP 100 (7002) + cover ENG 2 (9311)
Sachtler-v-1563	System 15 SB ENG 2 MCF	DV 12 SB fluid head (1205) + tripod Speed Lock CF (5386) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004) + padded bag ENG 2 (9104)
Sachtler-1565	System 15 SB SL MCF	Video 15 SB fluid head (1505) + tripod ENG 2 CF (5386) + lightweight ground spreader SP 100 (7002) + cover ENG 2 (9311)
Sachtler-186251	System 18 S1 ENG 2 CF	Video 15 SB fluid head (1505) + Speed Lock CF (5386) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004) + padded bag ENG 2 (9104)
Sachtler-186351	System 18 S1 ENG 2 MCF	Video 15 SB fluid head (1505) + Speed Lock CF (5386) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004) + padded bag ENG 2 (9104)
Sachtler-186551	System 18 S1 SL MCF	Video 18 S1 fluid head (1810) + tripod ENG 2 CF (5386) + lightweight ground spreader SP 100 (7002) + padded bag ENG 2 (9104)
Sachtler-207251	System 20 S1 HD CF	Video 18 S1 fluid head (1810) + tripod ENG 2 CF (5386) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004) + padded bag ENG 2 (9104)
Sachtler-207351	System 20 S1 HD MCF	Video 20 S1 fluid head (2010) + tripod ENG 2 CF HD (5390) + heavy duty ground spreader SP 100/150 (7003) + padded bag ENG/EFP (9106)
Sachtler-207551	System 20 S1 LD HD MCF	Video 20 S1 fluid head (2010) + tripod ENG 75/2 D (4188) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004) + padded bag ENG/EFP (9106)
Sachtler-2570	System 25 C III	Video 20 S1 fluid head (2010) + tripod Speed Lock CF HD (5590) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004) + padded bag ENG/EFP (9106)
Sachtler-2580	System 25 Combi 1-40	Video 25 Plus FB fluid head (2501P) + Multi Disc (3914) + Pedestal C III (5195)
Sachtler-2512	System 25 EFP 2 CF	Video 25 Plus FB fluid head (2501P) + Multi Disc (3914) + Vario Pedestal 2-75 (5201)
Sachtler-2594	System 25 Studio	Video 25 Plus FB fluid head (2501P) + Multi Disc (3914) + Vario Pedestal 2-75 (5201)
Sachtler-3012	System 30 EFP 2 MCF	Cine 30 HD fluid head (3006) + tripod EFP 2 CF (6386) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004)
Sachtler-1973	System 7+7 HD MCF	Cine 7+7 HD fluid head (1910) + tripod ENG 2 CF HD (5390) + mid-level spreader 100/150 (7007) + rubber feet 100/150 (7004) + padded bag ENG/EFP (9106)
Sachtler-1012	System Ace L GS CF	Ace tripod system with 75 mm 2-stage carbon fiber tripod with spreader SP 75
Sachtler-1011	System Ace L MS CF	Ace L fluid head + tripod Ace 75/2 CF + set mid-level spreader Ace (7012) + Ace bag (9115)
Sachtler-1013	System Ace L TT 75/2 CF	Ace L fluid head + tripod TT 75/2 CF + Ace bag (9115)
Sachtler-1002	System Ace M GS	Ace M fluid head + tripod Ace 75/2 D + ground spreader SP 75 (7001) + Ace bag (9114)
Sachtler-1001	System Ace M MS	Ace M fluid head + tripod Ace 75/2 D with footpads with retractable spikes + mid-level spreader Ace + Ace bag (9114)
Sachtler-3025	System Cine 30	Cine 30 HD fluid head (3006) + front pan bar HD (3372) + tripod Cine 150 long (6290) + spreader Cine (7023)
Sachtler-371	System FSB 4 / 2 D	FSB 4 fluid head + tripod ENG 75/2 D (#4188) + spreader SP 75 (#7001) + padded bag DV 75 S (#9108)
Sachtler-373	System FSB 4 / 2 HD	FSB 4 fluid head (0307) + tripod ENG 75/2 D (#4188) + set mid-level spreader 75 (7011) + padded bag DV 75 S (9108)
Sachtler-375	System FSB 4 SL MCF	FSB 4 fluid head (0307) + tripod Speed Lock 75 CF (4588) + set mid-level spreader 75 (7011) + padded bag DV 75 S (9108)
Sachtler-471	System FSB 6 / 2 D	FSB 6 fluid head (#0407) + tripod ENG 75/2 D (#4188) + spreader SP 75 (#7001) + padded bag DV 75 S (#9108)
Sachtler-478	System FSB 6 / 2 HD M	FSB 6 fluid head (0407) + tripod ENG 75/2 D HD (S2034-0001) + set mid-level spreader 75 HD (7008) + padded bag (9108) 3.3-17.6 lbs (1.5-8 kg) payload
Sachtler-473	System FSB 6 / 2 M	FSB 6 fluid head (0407) + tripod ENG 75/2 D (4188) + set mid-level spreader 75 (7011) + padded bag DV 75 S (9108)
Sachtler-475	System FSB 6 SL MCF	FSB 6 fluid head (0407) + tripod Speed Lock 75 CF (4588) + set mid-level spreader 75 (7011) + padded bag DV 75 S (9108)
Sachtler-450	System FSB 6 TT 75/2 CF	FSB 6 T fluid head (0405) + tripod Speed Lock 75 CF (4588) + set mid-level spreader 75 (7011) + padded bag DV 75 S (9108)
Sachtler-477	System FSB 8 / 2 D CF	FSB 6 fluid head (0407) + telescopic tripod TT 75/2 CF + padded bag DV 75 L (9109)
Sachtler-771	System FSB 8 / 2 D	FSB 8 fluid head (#0707) + tripod ENG 75/2 D (#4188) + spreader SP 75 (#7001) + padded bag DV 75 S (#9108)
Sachtler-776	System FSB 8 / 2 HD	FSB 8 fluid head (0707) + tripod ENG 75/2 D HD (S2034-0001) + ground spreader SP 75 (7011) + padded bag (9108) 2.2-22 lbs (1-10 kg) payload
Sachtler-778	System FSB 8 / 2 HD M	FSB 8 fluid head (0707) + tripod ENG 75/2 D HD (S2034-0001) + set mid-level spreader 75 HD (7008) + padded bag (9108)
Sachtler-773	System FSB 8 / 2 M	FSB 8 fluid head (0707) + tripod ENG 75/2 D (4188) + set mid-level spreader 75 (7011) + padded bag DV 75 S (9108)
Sachtler-775	System FSB 8 SL MCF	FSB 8 fluid head (0707) + tripod Speed Lock 75 CF (4588) + set mid-level spreader 75 (7011) + padded bag DV 75 S (9108)
Sachtler-v-7		